



Speed Oven, Convection Steam Oven, and SO2450 Showroom Kit Installation

wolfappliance.com 800.222.7820

SPEED OVEN

CONTENTS	
1	Step-up transformer
1	Showroom power cord, 120 V

This kit is required to place Speed Ovens in Showroom mode (Demo mode). In Showroom mode, the lights and controls are enabled. All other operation is disabled.

ENTER SHOWROOM MODE


- 1 Touch Settings five times.
- 2 Touch 1.
- 3 Touch Start. "Demo on" appears on the control panel display. "Demo" remains on the display.

CONVECTION STEAM OVEN AND SO2450

CONTENTS	
1	Step-up transformer
1	Showroom power cord, 120 V

This kit is required to place Convection Steam Ovens and 24" E Series Ovens in Showroom mode (Demo mode). In Showroom mode, the lights and controls are enabled. All other operation is disabled.

ENTER SHOWROOM MODE

- 1 Touch .
- 2 Scroll to and touch Service.
- 3 Use the number pad to enter 6301, then touch Ok.
- 4 Touch Demo mode, then touch On.

